



VEICHI VC Series Ethernet(TCP)


| | |
|---|---|
| VEICHI | 1 |
| ❖ 1 Introduction to Drive | 2 |
| ❖ 2 HMI configure | 3 |
| ❖ 3 External controller configuration..... | 4 |
| ❖ 4 Supported register type | 7 |
| ❖ 5 Advanced parameters and error messages..... | 7 |
| ❖ 6 Software Configuration | 7 |

❖ 1 Introduction to Drive


| | |
|--------------------|---|
| Driver protocol | VEICHI VC Series Ethernet(TCP) |
| PLC Model number | VEICHI VC1S、VC1、VC2、VC3、VC5 Model number |
| website | https://www.veichi.cn/ |
| communication mode | Ethernet |
| PLC interface | Ethernet |
| PLC port number | Modbus TCP: 502 |
| Online simulation | support |
| HMI Model | F2 / G2 full series (with network port) |

Hardware wiring method: If PLC communicates directly with HMI without HUB or SWITCH, crossover cable is used; If the network communicates with the HMI through the HUB or SWITCH, use either a direct connection or a crossover cable.

A. Crossover cable wiring diagram



B. Wiring diagram of the direct cable



❖ 2 HMI configure

➤ Configure communication connections




Figure1

- 1) Engineering - Communication connection - Ethernet, select the network port to add the driver;
- 2) Click the "Add" button;
- 3) The input field after the word "company" is to select the manufacturer; Select a communication protocol in the input field next to Protocol. Select the external controller brand Veichi. (If no corresponding controller manufacturer is available, refer to the Common Device Management manual for configuration.) VEICHI VC Series Ethernet protocol is selected as the communication protocol;

- 4) Set the IP, station number and port number of the controller, which can be set directly or by clicking the "Set" button; The default port number of the software is 502. If the port number of the PLC is changed, the port number must be the same as that of the PLC.
- 5) After confirming the parameters, click OK to complete the configuration of the communication connection.

➤ Create variables

- 1) Variables - External variables Select the PLC to create the variable;
- 2) Click Add on the right and create according to the required data type;
- 3) According to the actual need to use the register in this position, it is necessary to pay attention to the type of PLC and how many bits of symbol number to correspond;
- 4) The variable name can be changed;
- 5) If there is a variable group established, you can choose to store the variable in the corresponding variable group;
- 6) After the array function is enabled, the length of the variable can be set according to the address range of the corresponding register, which is easy to copy multiple register variables of the same kind;

After confirming the Settings, click OK to create a new one




Figure2

❖ 3 External controller configuration

The software used in this manual is Vitron PLC programming software Auto Studio V1.12.8.6.

Download link (<https://www.veichi.cn/service/datadownload/>)

- (1) Open Auto Studio software, create a project, set the project name, path, model and other information, and then confirm:




Figure3

- (2) Click "EtherNet" in the left list --> "Ethernet Settings", you can edit the PLC IP address, gateway and other information, need to pay attention to the port number and one of the corresponding:




Figure4

- (3) Choose PLC Connection ----> Connection Settings. The driver is a network port driver. Therefore, select the network port and set the peer IP address of the PLC. You can also click search to find the IP address of the PLC connected.




Figure5

- (4) After writing PLC program, click "PLC" ----> "download", after downloading, it will automatically check whether the program is wrong, after downloading, click "debug" ----> "monitor" to monitor the PLC register (when monitoring register, input "register name" in the information output window below, such as "C0", Then select the corresponding data type to confirm whether it is a bit variable or a word variable, and then adjust the displayed decimal, you can monitor the value change of the corresponding register, you can also enter the changed value at the new value to observe the change).

| Element Name | data type | display format | current |
|--------------|-----------|----------------|---------|
| C0 | BOOL | Binary | ON |
| C1 | BOOL | Binary | ON |
| C2 | BOOL | Binary | ON |
| C3 | BOOL | Binary | ON |
| C4 | BOOL | Binary | ON |
| C5 | BOOL | Binary | OFF |
| C6 | BOOL | Binary | OFF |
| C7 | BOOL | Binary | OFF |
| C8 | BOOL | Binary | OFF |
| C9 | BOOL | Binary | OFF |
| C10 | BOOL | Binary | OFF |
| C11 | BOOL | Binary | OFF |

Figure6

❖ 4 Supported register type

| Device | Bit Address | Word Address | Format | Notes |
|--------------------|---------------|-----------------|--------|-------------|
| 16-bit counter | C1 0-255 | ---- | DDD | |
| 32-bit counter | C2 256-511 | ---- | DDD | |
| 16-bit timer | T1 0-255 | ---- | DDD | |
| 32-bit timer | T2 256-511 | ---- | DDD | |
| Status relay | S1 0-1023 | ---- | DDDD | |
| Status relay | S2 1024-4095 | ---- | DDDD | |
| Special register | SM1 0-255 | ---- | DDD | |
| Special register | SM2 256-1023 | ---- | DDDD | |
| Auxiliary register | M1 0-2047 | ---- | DDDD | |
| Auxiliary register | M2 2048-10239 | ---- | DDDDD | |
| Input register | X 0-777 | ---- | OOO | |
| Output register | Y 0-777 | ---- | OOO | |
| 32-bit counter | ---- | CD1 200-255 | DDD | double-word |
| 32-bit counter | ---- | CD2 256-263 | DDD | double-word |
| Data register | ---- | R 0-32767 | DDDDD | |
| 16-bit counter | ---- | C 0-199 | DDD | |
| timer | ---- | T1 0-255 | DDD | |
| timer | ---- | T2 256-511 | DDD | |
| Internal register | ---- | Z 0-15 | DD | |
| Data register | ---- | D 0-7999 | DDDD | |
| Data register | ---- | D_D word 0-7998 | DDDD | double-word |
| Special register | ---- | SD1 0-255 | DDD | double-word |
| Special register | ---- | SD2 256-1023 | DDDD | double-word |

❖ 5 Advanced parameters and error messages

Reference Manual - Communication Advanced Parameters and Error Information Table

❖ 6 Software Configuration

The following steps use the associated word variable as an example:





Figure7

- (1) Click "External Variables" and select the network port corresponding to VEICHI VC Series Ethernet(TCP Slave).
- (2) Click "Add" to pop up the create new variable window;
- (3) Select the word variable in the register type;
- (4) Select "Array" and select the array length;
- (5) Click "OK" to complete the variable creation operation;
- (6) Click "Components";
- (7) Select the "Value Display" component;
- (8) Select the Value Display option.
- (9) The binding variable can be entered directly into the register or through the "...". Select a variable (you can also create a new variable here, same steps 2 to 5);
- (10) Select the required register content and bind;
- (11) Select array subscript;

(12) Click "OK" to complete variable selection;

(13) Click "OK" to complete the operation of the value element associated word variable;